


















INSTALLATION INSTRUCTION

DSD0206-1






◆ Assembly Drawing




[1]		x2	[2]		x1	[3]		x4	[4]		x4	[5]		ST4x10 x2
[6]		x2	[7]		x1	[8]		x1	[9]		ST4x8 x2	[10]		x2
[11]		ST4x12 x12	[12]		x12	[13]		x12	[14]		x12	[15]		x1


Tools list




◆1






◆2




◆3




◆4




◆5




◆6



◆7



◆8



on hold 24 hours
prior putting in use.

